


FITTING INSTRUCTION

| Clamp mark in acc. with | | Cables joining |
|----------------------------|-----|---------------------------|
| ISO | PN | |
| 1 | L | Left directional lights |
| 2 | + | Rear fog lights |
| 3 | 31 | Ground |
| 4 | R | Right directional lights |
| 5 | 58R | Right side parking lights |
| 6 | 54 | Stoplights |
| 7 | 58L | Left side parking lights |



This towing hitch is designed to assembly in following cars:
RENAULT MEGANE I GRANDTOUR, ESTATE (KA), produced since
 04.1999 till 08.2003, catalogue no. **G33A** and is prepared to tow trailers
 max total weight **1350 kg** and max vertical load **75 kg**.

From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and correct exploitation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be install in points described by a car producer.

The instruction of the assembly

1. From below the car, in rear slice, find plugged holes (on the left and right side). Open it and put caget nut in (pos. 13).
2. Main bar of the towing hitch (pos. 1) put from below and through holes (pos. A) and fix by bolts M8 as shown on the figure (use big washers pos. 15).
3. In original holes in chassis members put distance sleeves (pos. 6) – from outside.
4. To installed main bar (pos. 1) fix side brackets (pos. 4 and 5). Use bolts M10x30mm (pos. 9) through holes (pos. B).
5. Fix elements (pos. 4 and 5) through placed distance sleeves in chassis members and holes of the towing hitch by bolts M10x90mm (pos. 8) and by bolts M10x120mm (pos. 7).
6. Fix body of the automat and place tow-ball according to supplied instruction. Note! Remember to place socket plate (pos. 3) as shown on the drawing 1.
7. Tighten all bolts according to the torque shown in the table.
8. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station)
9. Complete paint layer damaged during installation.

Torque settings for nuts and bolts (8,8):

| | | |
|---------------------|----------------------|---------------------|
| M6 - 11 Nm | M 8 - 25 Nm | M 10 - 50 Nm |
| M 12 - 87 Nm | M 14 - 138 Nm | M16 - 210 Nm |



















NOTE

After install the towing hitch you should get adequate note in registration book (at authorised service station).The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.

Towing hitch accessories:

| | | | | | | | |
|-----------|--|-----------|---|------------|---|------------|--|
| Pos. 1 | Main bar  PCS.: 1 | Pos. 5 | Left bracket  PCS.: 1 | Pos. 10 | Bolt 8.8 B M8x30mm  PCS.: 4 | Pos. 15 | Washer ø24xø8.4x2mm  PCS.: 6 |
| Pos. 2 | Tow ball (mounting set)  PCS.: 1 | Pos. 6 | Distance sleeve ø17.2x2.35mm L=53mm  PCS.: 2 | Pos. 11 | Nut 8 B M10  PCS.: 5 | Pos. 16 | Washer ø10.5mm  PCS.: 4 |
| Pos. 3 | Socket plate  PCS.: 1 | Pos. 7 | Bolt 8.8 B M10x120mm  PCS.: 1 | Pos. 12 | Nut 8 B M8  PCS.: 2 | Pos. 17 | Spring washer ø10.2mm  PCS.: 6 |
| Pos. 4 | Right bracket  PCS.: 1 | Pos. 8 | Bolt 8.8 B M10x90mm  PCS.: 1 | Pos. 13 | Special nut M8  PCS.: 2 | Pos. 18 | Spring washer ø8.2mm  PCS.: 6 |
| | | Pos. 9 | Bolt 8.8 B M10x30mm  PCS.: 4 | Pos. 14 | Washer ø30xø10.5x2.5mm  PCS.: 2 | | |



PPUH AUTO-HAK Sp.J.

Produkcja Zaczepów Kulowych
Henryk i Zbigniew Nejman
76-200 SŁUPSK ul. Słoneczna 16K
tel/fax (059) 8-414-414; 8-414-413
E-mail: office@autohak.com.pl
www.autohak.com.pl

Towing hitch (without electrical set)

Class: **A50-X** Cat. no. **G33A**

Designed for:

Manufacturer: **RENAULT**

Model: **MEGANE I GRANDTOUR**

Type: **ESTATE (KA)**

produced since 04.1999 till 08.2003

Technical data:

D-value: 7,56 kN

maximum trailer weight: **1350 kg**

maximum vertical cup load: **75 kg**

Approval number acc. to regulations EKG/ONZ 55.01: **E20-55R-01 1742**

Foreword

This towing hitch is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch. The vehicle manufacturer's specifications regarding trailer load and max. vertical cup load are decisive for driving, and values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \times \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \text{Max vehicle weight [kg]}} \times \frac{9,81}{1000} = D \text{ [kN]}$$