### Towing hitch accessories:

Towing men accessories.							
Pos. Main bar	Pos. Bolt 8,8 B 5 M12x1.25x35m	m	Pos. Plain washer 10 ø13mm				
PCS.:1	PCS.: 4	0	PCS.: 4				
	Pos. Bolt 8,8 B M10x30mm	ØP)	Pos. Plain washer 11 ø10.5mm	0			
Pos. Tow ball pcs.: 1	Pos. Nut 8 B 7 M16 PCS.: 2		Pos. Spring washer #12 #16.3mm				
Pos. Socket plate  PCS.: 1	Pos. Nut 8 B M10	<b>©</b>	Pos. Spring washer 912.2mm	0			
Pos. Bolt 8,8 B M16x50mm	Pos. Plain washer 917mm		Pos. Spring washer #010.2mm	0			
			Pos. Ball cover PCS.:1	0			



### PPUH AUTO-HAK S.J.

Produkcja Zaczepów Kulowych Henryk & Zbigniew Nejman 76-200 SŁUPSK ul. Słoneczna 16K tel/fax (059) 8-414-414; 8-414-413 E-mail: office@autohak.com.pl www.autohak.com.pl

# **Towing hitch (without electrical set)**

Class: A50-X Cat. no. O25

Designed for:

Manufacturer: **TOYOTA** 

Model: **RAV-4**Type: 3/5 doors

produced since 06.1994 till 07.2000

Technical data: **D**-value: **9,0 kN** 

maximum trailer weight: 1750 kg maximum vertical cup mass: 75 kg

Approval number according to Directive 94/20/EC: e20\*94/20\*0391\*00

### **Foreword**

This towing hitch is designed according to rules of safety traffic regulations. The towing hitch is a safety component and can be install only by qualified personnel. Any alteration or conversion of the towing hitch is prohibited and would lead to cancellation of design certification. Remove insulating compound and underseal from vehicle (if present) in the area of the matting surfaces of the towing hitch.

The vehicle manufacturer's specifications regarding trailer mass and max. vertical cup mass are decisive for driving whereat values for the towing hitch cannot be exceeded.

D-value formula:

$$\frac{\text{Max trailer weight [kg]} \quad \text{x} \quad \text{Max vehicle weight [kg]}}{\text{Max trailer weight [kg]} + \quad \text{Max vehicle weight [kg]}} \text{X} \quad \frac{9,81}{1000} = \quad D \quad [kN]$$

#### FITTING INSTRUCTION

Clamp m in acc. w	nark	Cables joining	
	PN	Cables Johning	
	L	Left directional lights	
	+	Rear fog lights	
	31	Ground	A
	R	Right directional lights	
5 58	8R	Right side parking lights	
	54	Stoplights	
7 5	8L	Left side parking lights	5 —
<b>P</b>	5	- A 1 -	

This towing hitch is designed to assembly in following cars: **TOYOTA RAV-4, 3/5 doors,** produced since 06.1994 till 07.2000, catalogue no. **O25** and is prepared to tow trailers max total weight **1750 kg** and max vertical mass **75 kg**.

# From manufacturer

Thank you for buying our product. Their reliability has been confirmed in many tests. Reliability of towing hitch depends also on correct assembly and right operation. For this reasons we kindly ask to read carefully this instruction and apply to hints.

The towing hitch should be install in points described by a car producer.

## The instruction of the assembly

- 1. Unscrew factory-made towing eye (will not be assembled again).
- 2. Apply the main bar of the towing hitch (pos. 1) to frame of the car and through holes A of the towing hitch and existing in the frame threaded holes fix using bolts M12x1.25x35mm (pos. 5) from the towing hitch accessories.
- 3. Fix tow-ball (pos. 2) using bolts M16x50mm (pos. 4) from accessories.
- 4. Fix socket plate (pos. 3) using bolt M10x30mm (pos. 6).
- 5. Tighten all bolts according to the torque shown in the table.
- 6. Connect electric wires of 7-poles socket according to the instruction of the car. (Recommend to make at authorized service station).
- 7. Complete paint layer damaged during installation.

Torque settings for nuts and bolts (8,8):					
<b>M6 -</b> 11 Nm	<b>M8 -</b> 25 Nm	<b>M10 -</b> 50 Nm			
<b>M12 -</b> 87 Nm	<b>M14 -</b> 138 Nm	<b>M16</b> - 210 Nm			

### **NOTE**

After install the towing hitch you should get adequate note in registration book (at authorised service station). The car should be equipped with:

- Indicators
- Tow mirrors

After 1000km check all bolts and nuts. The ball of towing hitch must be always kept clear and conserve with a grease.